


ALUMINUM LOADING RAMP INSTRUCTIONS

Ramps are intended for specific applications and it is imperative the ramp that you have purchased is not used for any other application than its intention. Please carefully read and comply with the instructions on how to use quality loading ramps

Instructions are as follows:

- 1.) The bolt must be inserted and hand-tightened through the barrel hinge.
- 2.) Ramp surface must be dry, clean and free from oil or grease.
- 3.) Park vehicle or trailer on flat, firm ground, be sure the vehicle is **PARKED** with emergency/parking brake **ON** and the engine turned **OFF**.
- 4.) Place ramps on the tailgate or trailer to accommodate the wheelbase of the loading vehicle.
- 5.) Ensure the plate or fingers of the ramp are securely in place.
- 6.) Install and secure safety straps. An illustration of how to secure the safety straps is as follows:



- 7.) **ALWAYS** attach safety strap(s). Make sure the strap is properly adjusted for length to prevent kick-back of the loading ramp.
- 8.) Ensure the safety strap does not allow rearward movement of the loading ramp.

Motorcycle use:

- 9.) **NEVER** ride a Motorcycle or any other motorized equipment up or down a single runner loading ramp.
- 10.) Slowly push machine up the ramps **MAKING SURE TIRES ARE CENTERED ON THE RAMP AT ALL TIMES**. (Two or more adult people are recommended for loading)
- 11.) Acceleration must be slow, controlled and constant. The operator must remain in control of machinery at all times during loading and unloading.
- 12.) Use the brake as necessary to control your speed while unloading. Sudden or erratic braking or accelerating will cause ramps to pull away from the tailgate or trailer or even broke the ramp.

ATV use:

- 13.) Always have a second adult to spot for the rider when loading.
- 14.) Slowly drive machine up the ramps **MAKING SURE TIRES ARE CENTERED ON THE RAMP AT ALL TIMES**.
- 15.) Acceleration must be slow, controlled and constant. The operator must remain in control of machinery at all times during loading and unloading.
- 16.) Use the brake as necessary to control your speed while unloading. Sudden or erratic braking or accelerating will cause ramps to pull away from the tailgate or trailer or even broke the ramp.

WARNING – NEVER EXCEED THE MAXIMUM LOAD CAPACITY OF THE RAMPS. USE AT YOUR OWN RISK.

Failure to follow these procedures may result in damage to machinery, injury or death. The seller is not responsible for misuse or damages incurred during the use of the ramps. Copyright (2008)